


Eager Beaver Trailers

TAILBOARD for STROBES with SWITCH on TRAILER

Power to Switch via Black Wire

Note: Black Wire may also be switched at tractor for remote On-Off Control. If configured for remote On-Off, trailer tailboard switch must remain in ON position



Black
Green
Red
Yellow
Brown
White

For configurations which do NOT have a tailboard switch, Strobes are controlled from the tractor cab with switched power to the Black Wire

Note: If there is a Strobe Switch Lead on the Tailboard Harness, either a Jumper or Toggle Switch is required to close the black circuit

